


## Door Mirror Ground Lighting Bulb, Ground Lighting, Door Mirror, Replacing

### Removal

#### Lamp and bulb assembly



- Angle the mirror glass upwards/outwards
- Insert a screwdriver in the opening and press in the catch to release the lighting
- Twist the bulb holder free. Disconnect the bulb.

### Installation

#### Lamp and bulb assembly

- Install the bulb
- Insert the bulb holder and press into place.